



Sniff'n'Stop

Animal Chewing Deterrent

Trowelable Putty Kit

INSTALLATION INSTRUCTIONS



IPAK Mixing Instructions

- GENTLY PEEL the Red Rod from the Clear **IPAK** Channel.
- HOLDING the **IPAK** in one hand, KNEAD the contents using the fingers of the other hand.
- KNEAD the contents of the pouch until the COLOR is UNIFORM.
- CUT corner of the **IPAK** Sleeve to DISPENSE.

Application

- Wearing the Disposable Poly Gloves (supplied), SQUEEZE the mixed Sniff'n'Stop Putty into your hand.
- SMEAR the mixed Sniff'n'Stop onto the irregular animal chewing surfaces.

Properties

Working Time	-	4-6 hrs. (@77°F)
Tack Free Time	-	12 hrs. (@77°F)
Thorough Cure Time	-	72 hrs. (@77°F)
Clean-Up Solution	-	Soap, Water, and Rubbing Alcohol
Coverage	-	IP-SNS-012 and -112 1 sq. ft.
(on flat surface)	-	IP-SNS-050 and -150 4 sq. ft.



IFOAM Specialty Products
Corporation