



Sniff'n'Stop™



Wood Pole Capping Putty Trowelable Putty

IPAK INSTALLATION INSTRUCTIONS

IPAK Clip-Paks



Mixing Instructions

- **GENTLY PEEL** the **RED** Rod from the **CLEAR IPAK** Channel.
- **HOLDING** the **IPAK** in one hand, **KNEAD** the contents using the fingers of the other hand.
- **KNEAD** the contents of the pouch until the **COLOR** is **UNIFORM**.

Application Instructions

- **CUT** corner of the **IPAK** Sleeve to **DISPENSE**.
- **SQUEEZE** contents of the **IPAK** Sleeve onto the pole top.
- **TROWEL** the mixed **SNIFF'n'STOP** Putty over the entire surface of the pole top.

PROPERTIES

Working Time	-	4-6 hrs. (@77°F)
Tack Free Time	-	12 hrs. (@77°F)
Thorough Cure Time	-	72 hrs. (@77°F)
Clean-Up Solution	-	Soap, Water and Rubbing Alcohol
Coverage (on flat surface)	-	IP-CAP-012 - 1 sq. ft. IP-CAP-050 - 4 sq. ft.



IFOAM Specialty Products
Corporation